# finder ®

SWITCH TO THE FUTURE

YESLY GATEWAY TUTORIAL

YESLY Gateway configuration proceedings

YESLY

Connect the Micro USB connector to the Gateway and the power supply to the electrical socket before starting the steps.

01

Get into the Finder Yesly app where the house is displayed. Then press the settings icon at the top right.

So, you get into the settings menu from where press on "Gateways" to start the device pairing

02

03

CASA YESLY

Gateways
no gateways

Get your gateway!

Your active plant does not have any configured gateway.

Press on the '+' icon to start the pairing.

04

ADD NEW GATEWAY

Make sure you are close to the gateway.
Now the white LED turns ON and OFF slowly

Power up your gateway!

We are scanning for your gateway. Please, power it off, then switch it on again and make sure you are near to it.

finder®

YESLY

05

ADD NEW GATEWAY

Gateway found!

We found gg. If you want to configure it again, press the button below.

SETUP

When the app will find the Gateway, then press on 'SETUP'.

Name the Gateway, then press on 'CONTINUE'.

GATEWAY SETUP

Choose a name

You can assign a name to your gateway so you can recognize it more easily.

Gateway name
Gateway

CONTINUE

06

finder®

YESLY

07

GATEWAY SETUP

Connect to your Wi-Fi

Choose the Wi-Fi network to which the gateway must connect and enter the relevant password.

Wi-Fi
Home WiFi

Password
password

BACK   CONTINUE >

Select the network to link the device with, then insert the password.
Press on 'CONTINUE' to go on.

The app will follow itself three steps:
-WiFi network check

-Sending of the configuration (the gateway will be blinking fast)

-Device reboot
Press on 'CONTINUE' to go on.

08

GATEWAY SETUP

Configuring your gateway

✓ OK   Checking Wi-Fi connection
✓ OK   Sending configuration
✓ OK   Waiting for reboot

BACK   CONTINUE >

finder

YESLY

09

GATEWAY SETUP

Assigned to this gateway

● Kitchen

⊼ Chandelier ⊖

⊼ Spotlight ⊖

● Bathroom

♀ Dimmer ⊖

▦ Up / Down ⊖

● Living room

♀ Dimmer ⊖

● Bedroom

▦ Up / Down ⊖

FINISH ›

Choose the eventual devices that you do not want to control remotely, then press on 'FINISH'.

10

Yesly Home
no lights, 2 scenes

Kitchen
2 lights, no scenes

Bedroom
1 light, no scenes

Bathroom
2 lights, no scenes

Living room
1 light, no scenes

Cinema
Scene

Leaving home
Scene

Wait a few seconds until the gateway status icon turns green.
When the white LED turns steady ON, the system is correctly working.

finder

YESLY